



## Disposer START / STOP Procedures

### To Start Disposer

1. Turn Power ON.
2. Push Green **START** Button. (Pump will start and disposer will start 5 seconds later. This is to prevent splash up of standing water.)
3. MOV (drain) and Slurry MOV (drain) will close when **START** button is pressed.
4. Adjust bowl flush as desired.

### To Shutdown Disposer

1. Stop Feeding Waste Into Disposer For 5 Minutes. (Continue running for 5 minutes)
2. Push **TIMED STOP** Button to initiate clean cycle.
3. Push **STOP** button once for delayed stop. (MOV drain will open when unit stops)
4. Push **STOP** button *TWICE* to stop unit immediately.
5. **After Unit Stops, Turn Power OFF.**
6. MOV (drain) will open once unit is stopped.
7. Clean Disposer.

**Always Turn Power Off Before Reaching Into Disposer**